

9 Schematic Diagrams


- This Document can not be used without Samsung s authorization.
- 9-1 MAIN POWER BLOCK Schematic Diagram (N36A)




- This Document can not be used without Samsung s authorization.
- 9-2 X242 INOUT MEMORY Schematic Diagram (N36A)





9-3 X242 INOUT MEMORY Schematic Diagram (N36A)



- This Document can not be used without Samsung s authorization.
- 9-4 X242 POWER Schematic Diagram (N36A)











9-5 TUNER & SPLITT Schmetic Diagram (N36A)

ATSC HALF NIM TUNER












9-6 STANDBY MICOM (WT61P6S) (N36A)





9-7 PC & HDMI INPUT Schmetic Diagram (N36A)




DVI SOUND INPUT










- This Document can not be used without Samsung s authorization.
- 9-8 AV INPUT / OUTPUT Schmetic Diagram (N36A)
















9-9 SIDE AV (N36A)








- This Document can not be used without Samsung s authorization.
- 9-10 MSP4450K Schmetic Diagram (N36A)




9-11 SOUND AMP(NTP3000) Schmetic Diagram (N36A)








9-12 MST3388 & SIL9185 Schmetic Diagram (N36A)




9-13 FBE (N36A)




9-14 SUB-FUNCTION Schmetic Diagram (N36A)


SUB FUNCTION I/F




9-15 MAIN POWER BLOCK Schematic Diagram (N34B)




9-16 STANDBY MICOM (WT61P6) Schematic Diagram (N34B)




9-17 SOUND PROCESSOR (MSP4450) Schematic Diagram (N34B)




9-18 SOUND AMP (NTP3000) & POP SOLUTION Schematic Diagram (N34B)




9-19 NIM TUNER 1410 Schmetic Diagram (N34B)








ATSC HALF NIM TUNER




- This Document can not be used without Samsung s authorization.
- 9-20 BACK AV IN / OUT Schmetic Diagram (N34B)











DEBUG / AUTO WALL

















9-21 SIDE AV IN / OUT Schmetic Diagram (N34B)











9-22 HDMI SWITCH & PC & HDMI INPUT Schmetic Diagram (N34B)




9-23 SVP-PX POWER BLOCK Schmetic Diagram (N34B)


SVP_PX_POWER




- This Document can not be used without Samsung s authorization.
- 9-24 VIDEO DECODER & SCALER (SVP-PX) Schmetic Diagram (N34B)




9-25 SVP-UX DDR MEMORY Schmetic Diagram (N34B)




9-26 LVDS & PWM CONTROL & PANEL I/F Schmetic Diagram (N34B)




9-27 LAKE (I2C & GPIO & USB & UART & INT) Schmetic Diagram (N34B)





9-28 LAKE (I2S IN/OUT & TS-IN & YCbCr-OUT) Schmetic Diagram (N34B)







9-29 LAKE (DDR MEMORY) Schmetic Diagram (N34B)










- This Document can not be used without Samsung s authorization.
- 9-30 LAKE (STATIC MEMORY & DEBUG) Schmetic Diagram (N34B)









Debug Board I/F



9-31 LAKE (POWER BLOCK) Schmetic Diagram (N34B)









9-32 SUB FUCNTION Schmetic Diagram (N34B)

